

## **KEY SWITCH**

Install key switch in the outside(as the figure) and parallel(or series) connect with the power supply and electromagnetic lock.



